

Do I Need this Update?

AMP1-2SDA Release Notes

Basic Update Instructions:

1. Unzip the update package.
2. Copy the Wohler folder to a USB flash drive formatted with the FAT32 file system.
3. Remove power from the unit.
4. Insert the USB flash drive containing the update package.
5. Apply power to the unit.
6. When the main program has finished, remove the USB stick and allow the unit to boot.
7. Re-insert the USB stick to program the FPGA.
8. When the FPGA program has finished, remove the USB stick.
9. Your update is complete.

For detailed firmware update instructions, please consult Appendix A in the AMP1-2SDA manual.

Package E:

- Added factory reset menu item.
- Add mute option to ANLG and SPKR menus.
- Store last-selected input type and pair, and restore it on power-up.
- Reduce FPGA drive current.
- Fix FPGA update failure message

Package D:

- Not released

Package C:

- Not released

Package B:

- Allow main processor to report FPGA error.
- Lengthen USB detect time at startup to accommodate slower USB flash drives.

Package A:

- First customer release.