

# Software Upgrades

## Introduction

This chapter describes how to download a software update file to your computer, transfer it to a USB flash drive and install the update to an eAMP1-S8-2MDA unit.

## Download the Software

Software updates can be found at <https://www.wohler.com>, within the Support section, or contact Wohler Customer Support for more information.

Unzip and copy the update file(s) from your computer to the root directory (not inside of a folder) of a USB flash drive. It must be FAT32 file type, and does not need to be empty.

The USB flash drive, with Wohler Update Package(s) installed on it, must be inserted into the front panel USB jack of the eAMP1-S8-2MDA unit.